

**ЭНЕРГОМЕТРИКА**  
www.energometrika.ru

**Energom-207**

**Branch Circuit Power Meter**

**Installation & Operation Manual**  
**V1.16**

**⚠ Danger and Warning!**



This device can be installed only by professionals.

The manufacturer shall not be responsible for any accident caused by failure to comply with the instructions in this manual.

**⚠ Risks of Electric shocks, burning or explosion**

- This device can be installed and maintained only by qualified people.
- Before operating the device, isolate the voltage input, power supply and short-circuit the secondary windings of all current transformers.
- Put all mechanical parts, doors, or covers in their original positions before energizing the device.
- Always supply the device with the correct working voltage during its operation.

***Failure to take these preventive measures will cause damage to the equipment or injuries to people***

# CONTENTS

<b>1. PRODUCT INTRODUCTION .....</b>	<b>1</b>
1.1 OVERVIEW .....	1
1.2 PRODUCT FEATURES: .....	1
1.3 HMI HUMAN-COMPUTER INTERFACE .....	1
1.4 PRODUCT COMPOSITION.....	1
<b>2. PRODUCT PERFORMANCE AND FUNCTIONALITY .....</b>	<b>3</b>
2.1 PRODUCT MODEL.....	3
2.2 PRODUCT FUNCTION.....	8
2.3 TECHNICAL SPECIFICATION .....	9
2.4 EMC PROPERTIES .....	10
2.5 OPERATING ENVIRONMENT .....	10
<b>3. INSTALLATION .....</b>	<b>11</b>
3.1 MAIN MODULE DIMENSION.....	11
3.2 DI MODULE DIMENSION.....	11
3.3 HMI DIMENSION.....	12
<b>4. TERMINAL MARK AND CONNECTION WIRING .....</b>	<b>14</b>
4.1 MAIN MODULE TERMINALS (Energom-207-M).....	14
4.2 DI MODULE TERMINALS .....	15
4.3 HMI COMMUNICATION WIRING.....	15
4.4 HMI POWER SUPPLY WIRING.....	15
4.5 MAIN INCOME CIRCUIT HALL SENSOR WIRING .....	16
4.6 BRANCH CIRCUIT HALL SENSOR WIRING .....	17
4.7 INSULATION MONITOR HALL SENSOR WIRING .....	17
4.8 DC240V (OR DC336V) SYSTEM WIRING .....	18
4.8.1 DC240V main income circuit wiring.....	18
4.8.2 DC 240V branch circuit wiring.....	19
4.8.3 DC240V single main income wiring.....	20
4.8.4 DC240V two main income wiring.....	21
4.8.5 DC240V one main one spare income wiring.....	22
4.9 DC-48V SYSTEM WIRING .....	23
4.9.1 DC-48V main income circuit wiring .....	23
4.9.2 DC-48V branch circuit wiring.....	24
4.9.3 DC-48V single main income wiring .....	25
4.9.4 DC-48V two main income wiring.....	26
4.9.5 DC-48V one main one spare income wiring .....	27
4.10 DC336V SYSTEM WIRING .....	28
4.11 ADDRESS SETTING FOR MULTIPLE MAIN MODULE .....	29
<b>5. DISPLAY AND OPERATION.....</b>	<b>30</b>
5.1 SYSTEM CONFIGURATION .....	30
5.1.1 One main income configuration .....	30
5.1.2 Two main income configuration.....	30
5.1.3 One Main One Spare incoming configuration.....	31
5.1.4 Clear Energy data .....	31
5.1.5 Clear Maxim data .....	31
5.1.6 Time Synchronization.....	31

5.1.7 Function Configuration .....	31
5.1.8 Setting.....	32
5.1.9 Hall sensor calibration .....	32
5.1.10 Password Input.....	32
5.1.11 Password Modification .....	33
5.2 DATA DISPLAY.....	33
5.2.1 Real Time Data Display .....	33
5.2.2 Switch status display .....	33
5.2.3 Alarm display .....	33
5.2.4 Communication Status Indicate .....	33
5.2.5 Ground voltage and ground polarity.....	34
5.2.6 Key Instruction.....	34
5.3 MAIN INCOME CIRCUIT DATA DISPLAY .....	34
5.4 BRANCH CIRCUIT DATA DISPLAY .....	35
5.5 REAL-TIME ALARM RECORD DISPLAY .....	36
5.6 MAIN CIRCUIT PARAMETERS PROGRAMMING.....	37
5.7 BRANCH CIRCUIT PARAMETER PROGRAMMING.....	39
5.8 HISTORY ENERGY DATA .....	42
5.9 BRANCH CIRCUIT HALL SENSOR SETTING .....	43
5.10 BRANCH CIRCUIT MARK.....	43

# 1. Product Introduction

## 1.1 Overview

Energom-207 Branch Circuit Power Meter is specially designed for monitoring Power supply distribution cabinet in data center, which can monitor incoming circuit and branch circuit parameters, DI/DO status, fulfill

monitoring for power supply distribution cabinet and alarming for abnormal voltage and current information. 7 inch HMI with system chart display which can best fulfill visibility and operability, customer can choose 21 to 84 branch circuit by load quantity. This Energom-207 also provide extra RS485 communication port which can easily connect with other systems.

## 1.2 Product Features:

- Module design, separate Main module, CT module, Digital Input module, can fulfill different technical requirement
- 7 Inch HMI human-computer interface, good visibility and operability
- No extra secondary contact, each DI/DO switch has separate status indicate light
- Can measuring main income and branch circuit line insulation
- Can measuring one channel temperature.
- Relay alarm function, can record more than 5000 pieces alarming information
- Measuring the KWH on 2 loop incoming and each outgoing circuit, fulfill energy management requirement
- Adopt the DC hall sensor
- RS485 communication, Modbus-RTU protocol,

## 1.3 HMI Human-Computer Interface

Energom-207 branch circuit power meter with 7 inch touch screen human-computer interface, system chart display, with best visibility and operability.

## 1.4 Product Composition


Energom-207 Branch Circuit Power Meter with module design which including Main module (Energom-207- M), Branch circuit hall sensors, Branch circuit insulation monitor (Energom-207JY), Digital Input module, HMI module.

The Branch circuit insulation monitor (Energom-207JY) include main unit (Energom-207JY-M), insulation monitor hall sensor.

According to different application to choose different configuration, following are two main typical application for reference:

■ One main incoming circuit

One main circuit




Remark:

1. In one main circuit wiring system, each EnergoM-207 measure max. 42 branch circuits.
2. One main circuit max. has 84 branch circuits.
3. One HMI max. connect 2pcs of EnergoM-207 main modules to monitor 84 branch circuits.

Pic. 1.1

■ Two main incoming circuit

Two main circuits



Remark:

1. In two main circuit wiring system, each EnergoM-207 measure max. 42 branch circuits.
2. Each main circuit max. has 63 branch circuits.
3. One HMI max. connect 4pcs of EnergoM-207 main modules to monitor 126 branch circuits.

Pic. 1.2

## 2. Product Performance and functionality

### 2.1 Product Model

<b>Name</b>	Energom-207 Branch Circuit Power Meter	
<b>Model</b>	Energom-207-□- □- □ ① ② ③	
	① Alternative 21 or 42	21—Monitoring 21 branch circuits 42—Monitoring 42 branch circuits
	② Optional C1, C2, C3, C4, C5	C1—Branch circuit rated current 50A
		C2—Branch circuit rated current 100A
		C3—Branch circuit rated current 200A
		C4—Branch circuit rated current 400A
C5—Branch circuit rated current 600A		
③ Optional X1, X2, X3	X1—Rated voltage DC240V X2—Rated voltage DC48V X3—Rated voltage DC336V	
④ Optional T, L, TL	T—Measure 1 channel temperature, with PT100 sensor L—Measure 1 channel leakage current, rated 10mA (Primary) TL—Measure 1 channel temperature + 1 channel leakage current	

#### SPM207 modules

Item	Name	Model	Remark
1	HMI	Energom-207V7	7 inch HMI for local display, come with embedded monitoring software
2	Main module	Energom-207-42-C1-X1	
3	42 channel DI module	Energom206K-42 (dry contact)	Branch breaker config point OF
4	42 channel DI module	Energom206K-42 (DC 240V)	Get voltage from branch breaker
5	42 channel DI module	Energom206K-42 (DC -48V)	Get voltage from branch breaker , for system DC-48V

#### Other accessories


Item	Name	Model	Size drawing	Remark
1	50A hall sensor	LDCT-50K1	Pic2.1	For measuring branch circuit current
2	100A hall sensor	LDCT-100K1	Pic2.1	
3	200A hall sensor	LDCT-200K1	Pic2.1	
4	10mA leakage hall sensor	LDC10M	Pic2.2	For measuring branch circuit insulation, power supply DC12V, RS485 port
5	100A hall sensor	HOS-100AQ11	Pic2.5	For measuring main income circuit current, Split core, voltage output type
6	200A hall sensor	HOS-200AQ11	Pic2.5	
7	400A hall sensor	HOS-400AK1	Pic2.6	

8	600A hall sensor	HOS-600AK1	Pic2.6	
9	800A hall sensor	HOS-800AK2	Pic2.7	
10	1600A hall sensor	HOS-1600AK4	Pic2.8	
11	24V DC relay	MY2N-J	Pic2.9	Switch HMI main/ spare power supply
12	Temperature sensor	MS6-PT100B-3000	Pic2.10	




Hall Sensor Dimension:


Unit: mm



**Pic2.5**




**Pic2.6**




Use 2 nos of screw M3\*20 to fix on the busbar. On the copper busbar, Make two D4 through-holes.

**Pic2.7**



Use one (in middle) or two (two sides) screws M5\*10 fix on the copper busbar. (The copper busbar needs to be punched and tapped. The screw must be threaded through the copper busbar first. M5 nut is required for non-tapping.)

**Pic2.8**




OFS: Zero Adjustment  
GIN: Gain Adjustment


Terminal Instructions:  
1: Positive Port (+)  
2: Negative Port (-)  
3: Output Port (M)  
4: Common Port (G)

Use one (in middle) or two (two sides) screws M5\*10 fix on the copper busbar. (The copper busbar needs to be punched and tapped. The screw must be threaded through the copper busbar first. M5 nut is required for non-tapping.)

**24V DC Relay Dimension:**



**Temperature Sensor Dimension:**



**2.2 Product Function**

Function	Illustration
<b>Main Incoming Circuit</b>	
Main income measuring	Measuring voltage, and identify the polarity
Voltage to earth	Negative pole or Positive pole voltage to earth
Insulation measuring	Judging by voltage to ground
Temperature	1 channel temperature of Isolation transformer, range 0-120°C,
Income digital input ON/OFF status	4 DI to measure the ON/ OFF status of breaker or lightning protection switch. DI dry contact.
Incoming parameters	Voltage, Current, Max current, Active power, kWh
Demand data	Demand current, max demand current, demand P, max demand P
Incoming overload alarm	2 level alarm for higher limit current: Hi-limit alarm, Hi-hi- limit alarm
Incoming underload alarm	2 level alarm for lower limit current: Lo-limit alarm, Lo-lo- limit alarm
Incoming Over Voltage alarm	Over than setting voltage value will alarm

Incoming line Under Voltage alarm	Less than setting voltage value will alarm
Insulation resistance lower limit alarm	Less than setting insulation resistance value will alarm
Temperature alarm	Over than setting temperature value will alarm
DI ON/ OFF status alarm	When status ON change to OFF, it will alarm. This alarm function can be unable by software
<b>Branch Outgoing Circuit</b>	
Branch circuit monitoring	Can provide 21, 42 channel outgoing line circuit for choosing
Outgoing circuit digital input ON/ OFF status	Measure the 21, or 42 channel ON/ OFF status of breaker
Branch circuit parameters	Current, max current, active power, kWh
Branch circuit demand data	Demand current, max demand current, demand P, max demand P
Branch circuit overload alarm	2 level alarm for higher limit current: Hi-limit alarm, Hi-hi- limit alarm
Branch circuit underload alarm	2 level alarm for lower limit current: Lo-limit alarm, Lo-lo- limit alarm
DI ON/OFF status alarm	When status ON change to OFF, it will alarm. This alarm function can be unable by software
Insulation resistance lower limit alarm	2 level alarm for lower limit value: Lo-limit alarm, Lo-lo- limit alarm
<b>Others</b>	
Display module HMI	7 Inch touch screen, resolution 800x480
Communication Port	RS485, Modbus-RTU Protocol
Relay Output	2 relay as alarm port
Event record function	HMI can record more than 5000 pieces alarming events
Setting Function	Setting parameters by HMI, such as rated current, Alarm value
Running Indication	Main module and Digital Input module with running indicate LED light
DI ON/ OFF status Indication	Switching value indicating light
Pulse output for kWh	Can be configured to main circuit kWh or branch circuit kWh

## 2.3 Technical Specification

Name	Illustration
Power Supply	DC48V (36~60), DC 240V (110~370), or DC336V (110~400), power consumption <20W
Mean free error time	No less than 50000 hours
Rated Voltage	DC 240V or DC48V or DC 336V optional, Range: 10%~120% Un, Accuracy 0.5%
Main Income Circuit Rated Current	100A~1600A optional, Range: 1%~120% In, Accuracy: 0.5%
Rated Outgoing Current	50A, 100A, 200A, 400A, 600A optional, Range: 1%~120% In, Accuracy: 0.5%
Active Power and KWH	Accuracy: 1.0%
Communication port	RS485
Digital Input	Main Income Circuit 4DI: dry contact DI module for branch circuit: dry or wet for option. Wet contact signal DC240V, or DC-48V

Relay Capacity	AC 250V/5A or DC 30V/5A
----------------	-------------------------

## 2.4 EMC Properties


TEST	Technical Index	Standard
Electrostatic Discharge Immunity Test	Level 3	IEC61000-4-2
Radiated Immunity Test	Level 3	IEC61000-4-3
Electrical Fast Transient/Burst Immunity Test	Level 3	IEC61000-4-4
Surge Immunity Test	Level 3	IEC61000-4-5
Power Frequency withstand voltage	Rated Insulation Voltage <300V, Test Voltage 2000V Rated Insulation Voltage <60V, Test Voltage 1000V	IEC 62052-11: 2003

## 2.5 Operating Environment

Item	Parameter
Application Site	Indoor
Operating temperature	-10°C~55°C
Storage temperature	-25°C~70°C
Humidity	5%~95% RH, non-condensing
IP Grade	IP20, HMI (front panel) IP65
Insulation resistance	No less than 100MΩ, IEC62052-11

### 3. Installation


#### 3.1 Main module dimension



Pic. 3.1 Main Module drawing

[Note] : Use the screws to fix the main module.

#### 3.2 DI Module dimension



Pic. 3.2 DI Module dimension

Note:


1. DI Module fixed installation
2. Running Indication Light: Flash means normal working and on communication; Light normal ON, means normal working but no communication

### DI Module Address setting

One Main Module can connect one DI Module (42DI), the address of DI module setting by dial switch, setting dial switch as following




### 3.3 HMI dimension



Pic. 3.3 HMI Module





Pic. 3.4 HMI Installation

[Note]: HMI is Embedded panel mounting

## 4. Terminal mark and Connection Wiring

### 4.1 Main Module Terminals (EnergoM-207-M)

NO.	Mark	Definition	NO.	Mark	Definition
1	DC+	Power supply voltage, positive pole	20	24V-	DC24V power output
2	NC	Null	21	24V+	
3	DC-	Power supply voltage, negative pole	22	SHLD	No. 3 RS485 port, to system
4	V+	Main income voltage, positive pole	23	485C-	
5	NC	Null	24	485C+	
6	V-	Main income voltage, negative pole	25	SHLD	No. 2 RS485 port, to HMI
7	NC	Null	26	485B-	
8	PE	Earthing	27	485B+	
9	NC	Null	28	SHLD	No. 1 RS485 port, to DI module
10	+12V	Main circuit hall sensor power supply +12V	29	485A-	
11	-12V	Main circuit hall sensor power supply -12V	30	485A+	
12	I	Main circuit hall sensor current signal	31	S1	Digital input No. 1~4
13	GND	Main circuit hall sensor Earthing	32	S2	
14	IG	Main circuit leakage current signal	33	S3	
15	NC	Null	34	S4	
16	NC	Null	35	DC	DI common
17	NC	Null	36	NC	Null
18	NC	Null	37	RL22	Relay output 2
19	NC	Null	38	RL21	
			39	RL12	Reply output 1
			40	RL11	
			41	Pulse-	Pulse output
			42	Pulse+	
			43		
			44		
			45	PT-	PT100 input
			46	PT+	

## 4.2 DI module terminals

NO.	Mark	Definition	NO.	Mark	Definition
1	24V+	24V power supply, positive pole	28	S22	Digital input 22
2	24V-	24V power supply, negative pole	29	S23	Digital input 23
3	SHLD	Shielded earth	30	S24	Digital input 24
4	485-	RS485 -	31	S25	Digital input 25
5	485+	RS485 +	32	S26	Digital input 26
6	S1	Digital input 1	33	S27	Digital input 27
7	S2	Digital input 2	34	S28	Digital input 28
8	S3	Digital input 3	35	S29	Digital input 29
9	S4	Digital input 4	36	S30	Digital input 30
10	S5	Digital input 5	37	S31	Digital input 31
11	S6	Digital input 6	38	S32	Digital input 32
12	S7	Digital input 7	39	S33	Digital input 33
13	S8	Digital input 8	40	S34	Digital input 34
14	S9	Digital input 9	41	S35	Digital input 35
15	S10	Digital input 10	42	S36	Digital input 36
16	S11	Digital input 11	43	S37	Digital input 37
17	S12	Digital input 12	44	S38	Digital input 38
18	S13	Digital input 13	45	S39	Digital input 39
19	S14	Digital input 14	46	S40	Digital input 40
20	S15	Digital input 15	47	S41	Digital input 41
21	S16	Digital input 16	48	S42	Digital input 42
22	S17	Digital input 17	49	SG2	S22~S42 Common
23	S18	Digital input 18			
24	S19	Digital input 19			
25	S20	Digital input 20			
26	S21	Digital input 21			
27	SG	S1~S21 Common			

## 4.3 HMI communication wiring


There is one special cable to connect the HMI to the RS485 of EnergoM-207-M. The communication cable DB9 is connected to the HMI, the red line is connected to 485+, the yellow line is connected to 485-, plug and the shield is connected to SHLD.

## 4.4 HMI power supply wiring

HMI operation power supply is 24VDC, there are 2 types of connection.

- 1) There is no DI module: The HMI get power 24VDC from the main module EnergoM-207-M
- 2) There is DI module: The HMI get power 24VDC from the DI module


If the system has 2 main input, The HMI gets power from the 24VDC Relay, as below pic 4-1



Pic. 4.1

## 4.5 Main income circuit hall sensor wiring

### Wiring for Main Circuit Hall Sensor



Pic.4.2

Note:

1. Main circuit hall sensor has 4 terminals:

Power supply positive pole (+)

Power supply negative pole (-)


Output single (M)

Common grounding (G)

2. The EnergoM-207 main module terminal No. 10, 11, 13 provide power supply to the hall sensor. The terminals (M) connect

3. The arrow direction on hall sensor is the DC current flow direction (positive to negative), DC-48V install to Negative pole.

## 4.6 Branch circuit hall sensor wiring




Pic.4.3

### Note:

1. One Energom-207 main module can connect 42pcs of branch circuit hall sensors. The hall sensor has 4 terminals (+), (-), (M), (G). It has a cable to connect with main module. (Cable model No.: KF2510/4P)
2. The arrow direction on hall sensor is the DC current flow direction (positive to negative), DC-48V install to Negative pole.

## 4.7 Insulation monitor hall sensor wiring




Pic 4.4

### Note:

1. One Energom-207 main module can connect 42pcs of insulating sensors.
2. The insulating hall sensor need DC 12V power supply. The RS485 on sensor connect to the main module's RS485A.

## 4.8 DC240V (or DC336V) system wiring


### 4.8.1 DC240V main income circuit wiring



Pic 4.5

- Note:
1. One SPM207 main module can measure 42 branch circuits. If there are more than 42 circuits, users need to add main module. Max. monitor 84 branch circuits.
  2. One SPM207 main module has 4DI (dry contact) for monitoring the main circuit breaker status. Surge protection switch status and SPD faulty.
  3. SPM207 main module terminal No. 22, 23, 24 is the RS485 port for connecting 3rd party monitoring system.
  4. SPM207 main module gets power supply from the upper end of main circuit switch.
  5. NC is Null.


## 4.8.2 DC 240V branch circuit wiring



Pic 4.6

### 4.8.3 DC240V single main income wiring

#### Wiring for One Main Incoming Circuit System



Pic 4.7


Configuration table for different branch circuit Num.:  Require  No require

Branch circuit Num.	Energom-207 Main module	Energom-207 Main module	Remark
21 or 42	<b>1</b>	<b>2</b>	
63 or 84	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	



### 4.8.4 DC240V two main income wiring

### Wiring for Two Main Incoming Circuits System




Pic 4.8

Configuration table for different branch circuit Num.:  Require  No require

Branch circuit Num.	EnergoM-207 Main module	EnergoM-207 Main module	Remark
21 or 42	1	2	

### 4.8.5 DC240V one main one spare income wiring

#### Wiring for One Main + One Backup System



Pic 4.9


Configuration table for different branch circuit Num.:  Require  No require

Branch circuit Num.	Energom-207 Main module 1	Energom-207 Main module 2	Remark
21 or 42	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
6 or 84	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 4.9 DC-48V system wiring

## 4.9.1 DC-48V main income circuit wiring

### Main Circuit Wiring




Note:

1. One PilotSPM207 main module can measure 42 branch circuits. If there are more than 42 circuits, users need to add main module. Max. monitor 84 branch circuits.
2. One PilotSPM207 main module has 4DI (dry contact ) for monitoring the main circuit breaker status, Surge protection switch status and SPD faulty.
3. PilotSPM207 main module terminal No. 22, 23, 24 is the RS485 port for connecting 3rd party monitoring system.
4. PilotSPM207 main module gets power supply from the upper end of main circuit switch.
5. NC is Null.

Pic 4.10


## 4.9.2 DC-48V branch circuit wiring



Pic 4.11

### 4.9.3 DC-48V single main income wiring

#### Wiring for One Main Incoming Circuit System




Pic 4.12

Configuration table for different branch circuit Num.:  Require  No require

Branch circuit Num.	Energo M-207 module	EnergoM-207 Main module	Remark
21 or 42	<input checked="" type="checkbox"/> Module 1	<input type="checkbox"/> 2	
63 or 84	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

### 4.9.4 DC-48V two main income wiring

#### Wiring for Two Main Incoming Circuits System




Pic4.13

Configuration table for different outgoing circuit Num.:  Require  No require

Branch circuit Num.	EnergoM-20 7 Main module	EnergoM-20 7 Main module	Remark
21 or 42	1	2	

### 4.9.5 DC-48V one main one spare income wiring

#### Wiring for One Main + One Backup System



Pic 4.14

Configuration table for different outgoing circuit Num.:  Require  No require






Branch circuit Num.	Energom-207 Main module 1	Energom-207 Main module 2	Remark
21 or 42	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
63 or 84	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

## **4.10 DC336V system wiring**

*The wiring for DC336V system is same as DC240V system. It is only voltage change from DC240V to DC336V. Please refer to Chapter 4.8*



### 4.11 Address setting for multiple main module

	Main module	Dial Switch Setting ( ■ is the switch position)
Single main input or One main one spare, 21 or 42 branch circuits	Energom-207 -Main module No.1	ON  1 2 3 4
Single main input or One main one spare, 63 or 84 branch circuits	Energom-207- Main module No.1	ON  1 2 3 4
	Energom-207- Main module No.2	ON  1 2 3 4
Two main input, 63 or 84 branch circuits	Energom-207- Main module No.1	ON  1 2 3 4
	Energom-207- Main module No.2	ON  1 2 3 4

# 5. Display and Operation

## 5.1 System Configuration


After Power On, HMI displays the real time data, under real time data interface, press “System Config” button to enter into system configuration interface

### Notice

After Power ON, should finish main incoming line mode selection and Outgoing line circuits selection setting first, then to setting other parameters

### 5.1.1 One main income configuration


Set to One main income , as picture 5.1



Pic. 5.1

### 5.1.2 Two main income configuration


Set to two main income , as picture 5.2



Pic. 5.2

### 5.1.3 One Main One Spare incoming configuration


Set to “main + backup”, as picture 5.3



Pic. 5.3

### 5.1.4 Clear Energy data

Clear Main Module Energy data, as picture 5.4



Pic. 5.4

### 5.1.5 Clear Maxim data

**Clear max.data**

Clear all the Maxim value information in Main Module, e.g. Maxim Current value, Maxim Demand current etc

### 5.1.6 Time Synchronization


**Time sync.**

Synchronization time on HMI and Main Module

### 5.1.7 Function Configuration

**Function config**

Exchange to Information setting interface, as picture 5.5



Pic. 5.5

### 5.1.8 Setting

Set

Press SET, after input correct password for further operation, default password: 201

### 5.1.9 Hall sensor calibration

In case, when the breaker is OFF, the current data is not "0", users can do calibration for the hall sensor. When doing calibration, please make sure the power supply for hall sensor is connected, and the breaker position is OFF (no load).

Operation as below:

Click , input the password, after input correct password can do calibration

Precautions:

- 1) Before calibration, make sure that the outgoing circuit is not connected to the load.
- 2) Before calibration, make sure there is no leakage at the site.
- 3) Default password 201. After calibration, check the outgoing insulation resistance value. If the value is 10K, the calibration success, if not 10K, calibration fails.


### 5.1.10 Password Input

**Confirm password**

Please enter your password!

when Clear Maxim value, Time Synchronization, Function Configuration, Set system configuration, it require to input the password for further operation. Default password: 201


### 5.1.11 Password Modification



## 5.2 Data Display


### 5.2.1 Real Time Data Display


Power on the HMI, user can enter into home page of display as below picture 5.6, Display real-time data of one or two main incoming circuit and 21 branch outgoing circuit as well as the condition of switch status.




Pic. 5.6

### 5.2.2 Switch status display


Main Switch:  Is the condition of main circuit DI status, green means DI 1 is "OFF", red means DI 1 is "ON", Flash means " Error"

Branch Switch:  Is the condition of branch circuit DI status, green means DI is "OFF", red means DI is "ON", Flash means " Error"

### 5.2.3 Alarm display

 The alarm light will turn red and flash when event happen. Gray means no alarm.

### 5.2.4 Communication Status Indicate

 Green means the communication between HMI and main module is normal. Gray means no communication.

**5.2.5 Ground voltage and ground polarity**

"U+" is the positive-to-ground voltage, and the normal value is about 50%U, which becomes lower when grounding.

"U-" is the negative-to-ground voltage, and the normal value is about 50%U, which becomes lower when grounding.

'⊥' is the grounding polarity, and the display is '+' indicating that the positive pole is grounded, and the display is '-' indicating that the negative pole is grounded.

DC 240V system, usually if the insulation resistance is less than 24KΩ will be considered to be too low, the system may have leakage.

**5.2.6 Key Instruction**

**Next:** Enter to next System Interface

**IN Data:** Enter to main circuit data display interface

**Branch Data:** Enter to branch circuit data display interface

**Alarm Record:** Enter to Real-time alarm record interface

**System Config:** Enter to system configuration interface

**5.3 Main Income Circuit Data Display**

Display 1 loop incoming circuit real time data, as picture 5.7

IN A Real-time data			
Item	IN	Other	Unit
V	0		V
I	0		A
Load current	0.00		%
Max. I	0		A
Dmd_I	0		A
Max. dmd_I	0		A
P	0		W
Dmd_P	0		W
Max. dmd_P	0		W
Total kWh	0		kWh
Temperature			°C
IR			KΩ

IN B
IN Set
Back

Pic. 5.7

## 5.4 Branch Circuit Data Display

Display multi loop branch circuit real time data, as picture 5.8

Branch 1 to 6 real-time data								Module 1	Relay-1: OFF	Relay-2: OFF
Item/Branch	1	2	3	4	5	6	Unit			
mark										
I	0	0	0	0	0	0	A			
Max. I	0	0	0	0	0	0	A			
Dmd_I	0	0	0	0	0	0	A			
Max. dmd_I	0	0	0	0	0	0	A			
P	0	0	0	0	0	0	W			
Dmd_P	0	0	0	0	0	0	W			
Max. dmd_P	0	0	0	0	0	0	W			
Total kWh	0	0	0	0	0	0	kWh			
Load current	0.00	0.00	0.00	0.00	0.00	0.00	%			

Set DI
IR
Energy Record
Set Hall
Set Branch
Page Up
Page Down
Back

Pic. 5.8

**Keys instruction:**

**Set DI:** Enter to branch circuit DI alarm configuration

**Energy Record:** Enter to history energy data record interface

**Set Hall:** Enter to setting hall sensor rated current

**Set Branch:** Enter to branch circuit alarm configuration

**Page Up:** View pervious page data

**Page Down:** View next page data

**Back:** Back to previous menu

If the devices come with Insulation monitor, it will show the insulation resistance value, as below Picture 5.9

Branch 1 to 21 IR								
Branch 1 to 7								
Branch	1	2	3	4	5	6	7	Unit
Positive Electrode	0	0	0	0	0	0	0	KΩ
Negative Electrode	0	0	0	0	0	0	0	KΩ
Branch 8 to 14								
Branch	8	9	10	11	12	13	14	Unit
Positive Electrode	0	0	0	0	0	0	0	KΩ
Negative Electrode	0	0	0	0	0	0	0	KΩ
Branch 15 to 21								
Branch	15	16	17	18	19	20	21	Unit
Positive Electrode	0	0	0	0	0	0	0	KΩ
Negative Electrode	0	0	0	0	0	0	0	KΩ

Page Down
Alarm Settings
Back

Pic. 5.9

## 5.5 Real-time Alarm Record Display

Display Maxim 15 pieces alarm information, as picture 5.10

Real-time alarm		
Date	Time	Alarm description
2021/10/10	11:21:57	Main line-A, main module and HMI communication or power outage

Historical record   Page Up   Page Down   Back

Pic. 5.10

History Information Record:

Historical record		
Date	Time	Alarm description
2021/10/10	11:24:09	PowerOn Record

Page Up   Page Down   Back

Pic. 5.11



## 5.6 Main Circuit Parameters Programming

Configure main income circuit parameters and alarm value, as picture 5.12

IN A Set (Module- 1)					
COM add:	Hall CT Num	IR Num	Baud rate:	Parity:	SD breakdown Alarm
0	0	0	1200	None	Disable
Main breaker Alarm	Branch breaker Alarm	S2 alarm mode	S4 alarm mode		
Disable	Disable	ON TO OFF	ON TO OFF		
Relay-1	Relay-2	S1 function	S2 function	S3 function	S4 function
Universal	Universal	Universal	Universal	Universal	Universal
CT Primary	5	Current lo-lo-limit(A)	0	Temp. hi-limit(°C)	0
Voltage lo-limit(V)	0	Current lo-limit(A)	0	Tem alarm return (°C)	0
Voltage hi-limit(V)	0	Current hi-hi-limit(A)	0	V-positive alarm (V)	0
IR lo-limit(KΩ)	0	Current hi-limit(A)	0	V-negative alarm (V)	0
			Set	Read	Back

Pic. 5.12

Items	Setting range and Instruction	Remark
COM add	1~247	Default setting: 1
Hall CT Num.	Branch hall sensor Num.: 0~42,	Default setting: 42
IR Num.	Insulation sensor Num.: 0~42,	Default setting: 0
Rated current (CT primary)	5~2000 The setting value must be a multiple of 5.	Default setting: 5.
Baud Rate	1200, 2400, 4800, 9600, 19200 or 38400	Default setting: 19200
Parity	None, Odd, Even	Default setting: None
SD breakdown Alarm	<b>Disable:</b> No alarm for branch circuit SD breakdown <b>Enable:</b> Alarm for branch circuit SD breakdown	
Main breaker Alarm	<b>Disable:</b> No alarm for main circuit breaker <b>Enable:</b> Alarm for main circuit breaker	
Branch breaker Alarm	<b>Disable:</b> No alarm for branch circuit breaker <b>Enable:</b> Alarm for branch circuit breaker	
S2 alarm mode	<b>ON to OFF:</b> Alarm when S2 changes from ON to OFF <b>OFF to ON:</b> Alarm when S2 changes from OFF to ON	
S4 alarm mode	<b>ON to OFF:</b> Alarm when S4 changes from ON to OFF <b>OFF to ON:</b> Alarm when S4 changes from OFF to ON	
Relay Function: Relay-1/ Relay-2	<b>Universal:</b> universal relay, user can control it by Modbus function code 05. <b>RUN indication:</b> relay active when the EnergoM-207 runs.	

	<p><b>Alarm:</b> relay active when there is alarm event for main or branch circuit.</p> <p><b>IN Alarm:</b> relay active when there is alarm event for main circuit.</p> <p><b>OUT Alarm:</b> relay active when there is alarm event for branch circuit.</p> <p><b>Tem Alarm:</b> Relay active when the high temperature alarm. It will recover if the temperature back to normal.</p>	
Main Circuit DI Function: S1, S2, S3, S4	<p><b>Universal:</b> Universal digital input</p> <p><b>IN Breaker:</b> Main circuit breaker</p> <p><b>Spare:</b> Spare part</p> <p><b>Surge protection:</b> The surge protection switch</p> <p><b>SPD:</b> Surge Protection Device</p>	<p>If the DI is set to be Surge protection switch, the HMI will show ON / OFF status. When HMI show ON, it means the Surge protection switch is ON. When HMI shows OFF, it means the Surge protection switch is OFF. If the DI is set to be SPD, the HMI will show the SPD symbol. When there is SPD alarm, the symbol will flash.</p>
Current lo-lo-limit alarm	<p>5.0~2500.0A, 0 means no alarm function</p> <p>Alarm trigger: when <math>0 &lt; \text{current} &lt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	
Current lo-limit alarm	<p>5.0~2500.0A, 0 means no alarm function</p> <p>Alarm trigger: <math>\text{lo-lo limit value} &lt; \text{current} &lt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	
Current hi-limit alarm	<p>5.0~2500.0A, 0 means no alarm function</p> <p>Alarm trigger: <math>\text{hi-hi-limit value} &gt; \text{current} &gt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	
Current hi-hi-limit alarm	<p>5.0~2500.0A, 0 means no alarm function</p> <p>Alarm trigger: <math>\text{current} &gt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	
Voltage lo-limit alarm	<p>20.0-500.0V, 0 means no alarm function.</p> <p>Alarm trigger: <math>0 &lt; \text{voltage} &lt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	
Voltage hi-limit alarm	<p>20.0-500.0V, 0 means no alarm function.</p> <p>Alarm trigger: <math>\text{voltage} &gt; \text{setpoint}</math></p> <p>Alarm restore: 5s after alarm condition is eliminated.</p>	

Temperature hi-limit alarm	30.0—120.0 °C 0 means no alarm function. Alarm trigger: Temperature > setpoint Alarm restore: Temperature < setpoint, and 5s after alarm condition is eliminated.	
Temperature return	30.0—120.0 °C Return condition: Temperature < setpoint,	
Insulation resistance lo-limit alarm	15 --100KΩ, 0 means no alarm function. Alarm trigger: 0 < IR < setpoint Alarm restore: 5s after alarm condition is eliminated.	
Positive bus voltage alarm	0~250, 0 means no alarm function. Alarm trigger: voltage > setpoint Alarm restore: 5s after alarm condition is eliminated.	
Negative bus voltage alarm v	0~250, 0 means no alarm function. Alarm trigger: voltage > setpoint Alarm restore: 5s after alarm condition is eliminated.	

## 5.7 Branch Circuit Parameter Programming

Outgoing circuit alarm setting as picture 5.14

**Branch 1 alarm config**


Rated current(A):	50
Current lo-lo-limit(A)	0
Current lo-limit(A)	0
Current hi-limit(A)	0
Current hi-hi-limit(A)	0

Mark
Set
Page Up
Page Down
Back
Apply to All

Pic. 5.14

Items	Setting Range	Remark
Rated current	10~600A	
Current lo-lo-limit alarm	5.0~1000.0A, 0 means no alarm function. Alarm trigger: 0 < current < setpoint Alarm restore: 5s after alarm condition is eliminated.	
Current lo-limit alarm	5.0~1000.0A, 0 means no alarm function. Alarm trigger: lo-lo limit < current < setpoint Alarm restore: 5s after alarm condition is eliminated.	
Current hi-limit alarm	5.0~1000.0A, 0 means no alarm function. Alarm trigger: hi-hi limit > current > setpoint Alarm restore: 5s after alarm condition is eliminated.	
Current hi-hi-limit alarm	5.0~1000.0A, 0 means no alarm function. Alarm trigger: current > setpoint Alarm restore: 5s after alarm condition is eliminated.	

If the devices come with Insulation monitor, users need to set do setting as below:



Pic. 5.15

Items	Setting Range	Remark
Insulation resistance lo-limit alarm	15~100KΩ, 0 means no alarm function. Alarm trigger: 0 < IR < setpoint Alarm restore: 5s after alarm condition is eliminated.	
Insulation resistance lo-lo-limit alarm	15~100KΩ, 0 means no alarm function. Alarm trigger: 0 < IR < setpoint Alarm restore: 5s after alarm condition is eliminated.	

If users want to set alarm for branch circuit DI, please enter to the sub-menu “Set DI” , as below picture.

**Branch 1 to 21 Switch alarm configuration**

1	2	3	4	5	6
Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾
7	8	9	10	11	12
Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾
13	14	15	16	17	18
Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾	Disable ▾
19	20	21			
Disable ▾	Disable ▾	Disable ▾			

Set    Read    Back

## 5.8 History Energy Data

Display historical Year electrical degree value, as picture 5.16

XXXX Year		1 to 42 Yearly Kwh						IN	0.0	kWh
Branch	1	2	3	4	5	6	7	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	8	9	10	11	12	13	14	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	15	16	17	18	19	20	21	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	22	23	24	25	26	27	28	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	29	30	31	32	33	34	35	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	36	37	38	39	40	41	42	Unit		
Energy data	0	0	0	0	0	0	0	kWh		

Search last  Year

Pic. 5.16

Display historical Month electrical degree value, as picture 5.17

XXX Year XX Monthly		1 to 42 Monthly Kwh						IN	0.0	kWh
Branch	1	2	3	4	5	6	7	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	8	9	10	11	12	13	14	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	15	16	17	18	19	20	21	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	22	23	24	25	26	27	28	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	29	30	31	32	33	34	35	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch	36	37	38	39	40	41	42	Unit		
Energy data	0	0	0	0	0	0	0	kWh		

Search last  Monthly

Pic. 5.17

## 5.9 Branch Circuit Hall Sensor Setting

Display hall sensor specification as picture 5.18

1 - 3 Branch	4 - 6 Branch	7 - 9 Branch	10 - 12 Branch
<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A
<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A
<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A
<input type="radio"/> 400A	<input type="radio"/> 400A	<input type="radio"/> 400A	<input type="radio"/> 400A
<input type="radio"/> 600A	<input type="radio"/> 600A	<input type="radio"/> 600A	<input type="radio"/> 600A

13 - 15 Branch	16 - 18 Branch	19 - 21 Branch
<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A
<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A
<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A
<input type="radio"/> 400A	<input type="radio"/> 400A	<input type="radio"/> 400A
<input type="radio"/> 600A	<input type="radio"/> 600A	<input type="radio"/> 600A

Buttons: Set, Read, Back

Pic 5.18

## 5.10 Branch Circuit Mark

Each branch circuit can be marked with 8 characters which shall be combined of letters and numbers, as picture 5.18

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18
19	20	21			

Buttons: Set, Read, Back

Pic.5.19

---

**ЭНЕРГОМЕТРИКА**  
[www.energometrika.ru](http://www.energometrika.ru)