


PMAC202 Branch Circuit Power Meter

User Manual

V1.0

Installation & Operation Manual





⚠ Danger and Warning!

This device can be installed only by professionals.

The manufacturer shall not be responsible for any accident caused by failure to comply with the instructions in this manual.

⚠ Risks of Electric shocks, burning or explosion

- This device can be installed and maintained only by qualified people.
- Before operating the device, isolate the voltage input, power supply and short-circuit the secondary windings of all current transformers.
- Put all mechanical parts, doors, or covers in their original positions before energizing the device.
- Always supply the device with the correct working voltage during its operation.

Failure to take these preventive measures would cause damage to the equipment or injuries to people

Contents

1. PRODUCT INTRODUCTION.....	2
1.1 Overview	2
1.2 Product Features:	2
1.3 HMI Human-Computer Interface	2
1.4 Product Composition.	3
2. PRODUCT PERFORMANCE AND FUNCTIONALITY	5
2.1 Product Model	5
2.2 Product Function	6
2.3 Technical Specification	7
2.4 EMC Properties	8
2.5 Operating Environment.	8
3. INSTALLATION	9
3.1 Main module Index	9
3.1.1 Main Module Installation detail drawing	10
3.1.2 Main Module Dismantle detail drawing	10
3.2 Status Module Index	11
3.3 CT Module Installation Index	12
3.4 Outgoing Single Installation CT Index	12
3.4.1 CT Switching Module Index	12
3.4.2 50A Single CT Index	13
3.4.3 100A Single CT Index	13
3.4.4 200A Single CT Index	14
3.5 Incoming Line Leakage Current Transformer Index.	14
3.6 HMI Module Index	15
4. CONNECTION WIRING	16
4.1 Main Module Terminals.	16
4.2 Switching Value Module Terminals	17
4.3 CT Module Terminals	17
4.4 HMI Power Connection.	18
4.5 Incoming Line Connection Wiring	19
4.6 Outgoing Line Connection Wiring	20
4.7 One Way Incoming Line System Connection Wiring	21
4.8 Two Way Incoming Line System Connection Wiring	22
4.9 One Main & One Backup Incoming Line System Connection Wiring	23
4.10 Multi Main Module Address Setting	24

5. DISPLAY AND OPERATION	25
5.1 System Configuration	25
5.1.1 One way Incoming Line Configuration	25
5.1.2 Two way Incoming Line Configuration	25
5.1.3 One Main & One Backup Incoming Line Configuration	26
5.1.4 Clear Energy	26
5.1.5 Clear Maxim Value	27
5.1.6 Time Synchronization	27
5.1.7 Function Configuration	28
5.1.8 Setting	28
5.1.9 Password Input	28
5.1.10 Password Modification	28
5.2 Data Display	29
5.2.1 Real Time Data Display	29
5.2.2 Switch status display	29
5.2.3 Alarm display	29
5.2.4 Communication Status Indicate	29
5.2.5 Key Operation	30
5.3 Incoming Circuit Data Display	30
5.4 Outgoing Circuit Data Display	30
5.5 Real-time Alarm Record Display	31
5.6 Incoming Circuit Value Programming	32
5.7 Outgoing Circuit Value Programming	33
5.8 History Electrical Degree	35
5.9 CT Setting	36
5.10 Data Record	37
6. MAINTENANCE AND TROUBLE SHOOTING	38

1. Product Introduction

1.1 Overview

PMAC202 Branch Circuit Power Meter is specially designed for monitoring Power supply distribution cabinet in data center, which can monitor incoming circuit and outgoing circuit parameters, DI/DO status, fulfill monitoring for power supply distribution cabinet and alarming for abnormal voltage and current information. 7 inch HMI with system chart display which can best fulfill visibility and operability, customer can choose 21st – 168st (Unit: 21st) outgoing circuit by load quantity. This PMAC202 also provide extra communication port which can easily connect with other systems.

1.2 Product Features:

1. Metal case, efficiently electromagnetic interference shield
2. Module design, separate Main-body module, CT module, Digital Input module, can fulfill different technical requirement
3. 7 Inch HMI human-computer interface, good visibility and operability
4. No extra secondary contact, each DI/DO switch has separate status indicate light
5. Can measuring incoming circuit Null Line current
6. Can measuring incoming circuit Leakage current
7. Can measuring Null earth voltage
8. Can measuring outside temperature
9. Relay alarm function, can record more than 2000 pieces alarming information
10. Measuring the KWH on 2 loop incoming and each outgoing circuit, fulfill energy management requirement
11. Measuring harmonic of voltage and current, monitoring power supply quality
12. Current Transformer accuracy is 0.2%, make sure the measuring accuracy
13. Modbus-RTU protocol, Rs485 communication


1.3 HMI Human-Computer Interface

PMAC202 branch circuit power meter with 7 inch touch screen human-computer interface, system chart display, with best visibility and operability.


1.4 Product Composition

PMAC202 Branch Circuit Power Meter with module design which including Main-body module, Digital Input module, HMI module, CT module. According to different application to choose different configuration, following are two main typical application for reference:

- One Way Incoming Line:



■ Two Way Incoming Line:



2. Product Performance and functionality

2.1 Product Model

Name	PMAC202 Branch Circuit Power Meter	
Model	PMAC202-□-□-□-□-□ ① ② ③ ④ ⑤	
	① Alternative A or B	A- Basic Model Main Circuit measuring: 3 phase voltage, current, current unbalance, current demand per phase, maxim current demand, maxim current, active power (total/each phase), reactive power (total/each phase), power factor, frequency, active energy, reactive energy, voltage THD, current THD, neutral current, 4 status input, 2 relay output Branch Circuit measuring: current, active power, reactive power, power factor, active energy, reactive energy, current demand, maxim current demand, maxim current, current THD
		B- Advanced Type On the base of A Basic model, expanded status input for each branch circuit
	② Alternative 21 or 42	21- Monitoring 21 branch circuits A Type: One 21 loop CT module B Type: One loop CT module + One 21 loop Status module (Advanced Type)
		42- Monitoring 42 branch circuits A Type: Two 21 loop CT module B Type: Two loop CT module + Two 21 loop Status module (Advanced Type)
	③ Alternative M or S	M1- Branch Circuit 21 loop CT strip, Rated Current: 50A S1- Branch Circuit separate CT, Rated Current 50A S2- Branch Circuit separate CT, Rated Current 100A S3- Branch Circuit separate CT, Rated Current 200A
④ Alternative T、L、TL	T- One loop temperature measuring, PT100 device L- One leakage current measuring, rated current 1A (primary) TL- One loop temperature and One leakage current measuring	
⑤ Alternative W or Y	W- Branch Circuit External Status input Dry connection Y- Branch Circuit External Status input Wet connection	

2.2 Product Function

Function	Illustration
Incoming Line	
Null Line Current monitoring	Monitoring Null Line current of incoming line
Leakage Current monitoring	Incoming Line leakage current monitoring, Rated value is 1A (primary)
Temperature monitoring	One loop temperature monitoring, range: 0—120 degree. Measuring Isolation Transformer temperature
Incoming line Switch status monitoring	4 loop status used to measuring incoming line switch and lighting protection switch. External Wet connection
Incoming line electrical parameter measuring	including phase voltage, phase current, phase maxim current, current unbalance, each phase active power, total active power, total power factor, frequency, total KWH
Incoming line demand measuring	Each phase current demand, maxim current demand, each phase active power demand, each phase maxim active power demand, total active power demand, maxim total active power demand
Incoming Line Harmonic measuring	Phase voltage, current total harmonic distortion (2-31 st harmonic) of incoming line
Incoming overload alarm	Over than setting current value will alarm, it is UP limit alarm and Over UP limit alarm
Incoming underload alarm	Less than setting current value will alarm, it is Lower limit alarm and Over Lower limit alarm
Incoming line Current Unbalance alarm	Over than setting unbalance value will alarm, one setting value
Incoming line Over Voltage alarm	Over than setting voltage value will alarm, one setting value
Incoming line Under Voltage alarm	Less than setting voltage value will alarm, one setting value
Null Line Over Current alarm	Over than setting current value will alarm, one setting value
Incoming Line Voltage default phase Alarm	If there is any phase measuring voltage is 0, and exist another phase voltage higher than 20V at the same time, the Default phase alarm will work. There is no setting value for default phase alarm
Leakage current over current alarm	Over than setting current value will alarm, one setting value
Temperature alarm	Over than setting temperature value will alarm, one setting value
Outgoing Line	
Multi-channel outgoing line monitoring	Can provide 21 st , 42 nd loop outgoing line circuit for choosing
Outgoing Line Switch status monitoring	Monitoring multi-channel Switch ON/OFF status, No auxiliary contact is also OK
Outgoing Line electrical parameters measuring	Current, Maxim Current, Active Power, Reactive Power, Power Factor, KWH, Current THD
Outgoing Line Demand measuring	Current demand, Maxim current demand, Active Power demand, Maxim Active Power demand
Outgoing Line Overload Alarming	Over than setting current value will alarm, it is UP limit alarm and Over UP limit alarm
Outgoing Line Underload alarming	Less than setting current value will alarm, it is Lower limit alarm and Over Lower limit alarm

Switch status change alarm	Alarm for switch change from OFF to ON, can close by software
Others	
HMI	7 Inch touch screen, resolution 800x480
Communication Port	RS485 Modbus-RTU Protocol
Relay Output	2 relay as alarm port
Event record function	HMI can record more than 2000 pieces alarming events
Setting Function	Setting parameters by HMI, such as: CT Ratio, Alarm value
Running Indication	Main module and Digital Input module with running indicate light
Switch Status Indication	Switching value indicating light
Outgoing phase sequence configurable	Outgoing phase sequence can be configured by HIM or Communication
kWh Pulse output	Active Power pulse output can be configured as Incoming line or Outgoing line
Data Record	Record History KWH and Current for Year, Month of Incoming line and Outgoing line

2.3 Technical Specification

Name	Illustration
Power Supply	DC 24V, Range: 18~30V。
Mean free error time	No less than 50000 hours
Life time	10 Year
Rated Voltage	AC 220V phase voltage, Range: 10%~120% Rated Value; Accuracy: 0.5%
Rated Incoming line Current	5Aac, Range: 1%~120% Rated Value; Accuracy: 0.5%
Rated Outgoing Current	50Aac, 1%~120% Rated Value; Accuracy: 0.5%
Demand Measuring	Demand period 15 minutes, slip frequency time 1 minute
Rated Frequency	50Hz, Range: 45~60Hz, $\pm 0.01\text{Hz}$
Power Factor	Incoming circuit accuracy: 1%, Outgoing Circuit accuracy: 1%
Active Power and KWH	Incoming circuit accuracy: 1%, Outgoing Circuit accuracy: 1%
Leakage Current	1A ac, Range: 10%--120% rated, accuracy: 0.5%
Null-Earth Voltage	5V ac, Range: 10%--200% rated, accuracy: 0.5%
Communication port	RS485
Switch Status	Outgoing: Wet contact signal input, 220Vac, 70%--120% rated value or Dry contact input Incoming: Dry contact input
Relay Capacity	AC 250V/5A or DC 30V/5A

2.4 EMC Properties


Items	Technical Index	Standard
Electrostatic Discharge Immunity Test	Level 3	IEC61000-4-2
Radiated Immunity Test	Level 3	IEC61000-4-3
Electrical Fast Transient/Burst Immunity Test	Level 3	IEC61000-4-4
Surge Immunity Test	Level 3	IEC61000-4-5
Power Frequency withstand voltage	Rated Insulation Voltage \leq 300V, Test Voltage 2000V Rated Insulation Voltage \leq 60V, Test Voltage 1000V	GB/T 17215.211-2006

2.5 Operating Environment


Item	Parameter
Application Site	Indoor
Operating temperature	-10°C~55°C
Storage temperature	-25°C~70°C
Humidity	5%~95% RH, non-condensing
IP Grade	IP20, HMI (front panel) IP65
Insulation resistance	No less than 100M Ω , IEC62052-11

3. Installation

3.1 Main module Index




Picture 3.1 Main Module Index



Picture 3.2 Main Module Installation


[Note]: Main Module is Din-rail installation

3.1.1 Main Module Installation detail drawing




Picture 3.3 Main Module Installation detail drawing

3.1.2 Main Module Dismantle detail drawing



Picture 3.4 Main Module Dismantle detail drawing

3.2 Status Module Index




Picture 3.5 Status Module Index

- Note:
1. Status Module fixed installation
 2. Running Indication Light: Flash means normal working and on communication; Light normal ON, means normal working but no communication


Status Module Address setting

One Main Module can support 2 piece 21 loop Status Module, the address of status module setting by dial switch, setting dial switch as following



Picture 3.6 Module Address


3.3 CT Module Installation Index



Picture 3.7 CT Module Index


3.4 Outgoing Single Installation CT Index

3.4.1 CT Switching Module Index



Picture 3.8 CT Switching Module Index

3.4.2 50A Single CT Index




Picture 3.9 50A Single CT Index

[Note]:

Each CT equip with 2.5M cable, Black cable connect with CT Switching module same terminal. One CT Switching module can connect with 21 CT, 50A single CT be fixed by 2 M3*8 screw from bottom to rear panel

3.4.3 100A Single CT Index




Picture 3.10 100A Single CT Index

[Note]:

Each CT equip with 2.5M cable, Yellow cable connect with CT Switching module same terminal. One CT Switching module can connect with 21 CT, 100A single CT be fixed by 2 M3*8 screw from bottom to rear panel

3.4.4 200A Single CT Index




Picture 3.11 200A Single CT Index

[Note]:

Each CT equip with 2.5M cable, Yellow cable connect with CT Switching module same terminal. One CT Switching module can connect with 21 CT, 200A single CT be fixed by 2 M3*8 screw from bottom to rear panel


3.5 Incoming Line Leakage Current Transformer Index




Picture 3.12 Incoming Line Leakage Current Transformer

[Note]: Incoming Line Leakage Current Transformer standard is 250A

3.6 HMI Module Index



Picture 3.13 HMI Module Index



Picture 3.14 HMI Installation

[Note]: HMI Embedded panel mounting

4. Connection Wiring

4.1 Main Module Terminals


No	Definition	Instruction	No	Definition	Instruction
1	VA	Incoming Line Voltage measurement input	25	485A+	1 st RS485 communication to Status module
2	NC		26	SHLD	
3	VB		27	SHLD	2 nd RS485 communication to HMI
4	NC		28	485B-	
5	VC		29	485B+	
6	VN		30	SHLD	3 rd RS485 communication to System
7	IN1	31	485C-		
8	IN2	32	485C+	Null-GND line voltage measurement input	
9	IA1*	33	VN		
10	IA2	34	VG	PT100 input	
11	IB1*	35	PT-		
12	IB2	36	PT+	Relay 2	
13	IC1*	37	RL21		
14	IC2	38	RL22	Relay 1	
15	I Δ +	39	RL11		
16	I Δ -	40	RL12	kWh Pulse output	
17	24V2-	41	Pulse-		
18	24V2+	42	Pulse+	1-4 DI Status	
19	NC	43	NC		
20	24V1-	44	S4		
21	24V1+	45	S3		
22	24VO-	46	S2		
23	24VO+	47	S1	DI Status Common Terminal	
24	485A-	48	DC		

4.2 Switching Value Module Terminals

No	Definition	Instruction	No	Definition	Instruction
1	24V+	Positive pole of 24V power supply input	17	24V+	Positive pole of 24V power supply output
2	24V-	Negative pole of 24V power supply input	18	24V-	Negative pole of 24V power supply output
3	SHLD	Shielded earth	19	SHLD	Shielded earth
4	485A-	485 -	20	485A-	485 -
5	485A+	485 +	21	485A+	485 +
6	S1	DI 1 Input	22	S12	DI 12 Input
7	S2	DI 2 Input	23	S13	DI 13 Input
8	S3	DI 3 Input	24	S14	DI 14 Input
9	S4	DI 4 Input	25	S15	DI 15 Input
10	S5	DI 5 Input	26	S16	DI 16 Input
11	S6	DI 6 Input	27	S17	DI 17 Input
12	S7	DI 7 Input	28	S18	DI 18 Input
13	S8	DI 8 Input	29	S19	DI 19 Input
14	S9	DI 9 Input	30	S20	DI 20 Input
15	S10	DI 10 Input	31	S21	DI 21 Input
16	S11	DI 11 Input	32	SG	DI Status Common Terminal

4.3 CT Module Terminals

One CT module can connect with 21 branch circuits, each branch circuit cross the CT follow by phase ABC and repeated as below:




4.4 HMI Power Connection


HMI Power Supply is DC 24V, there are two kinds connection wiring:

1. If there is no Status Module, power supply from Main Module 24V DC power supply output terminal
2. If has Status module, power supply from last status module 24V DC power supply output terminal

For Two way Incoming line can exchange HMI power supply by one 24V relay, as following picture:




4.5 Incoming Line Connection Wiring




4.6 Outgoing Line Connection Wiring

PMAC202 Outgoing Line Connection Wiring



Note: When there is just one 21 loop CT module, the CT module just can connect with Main module just can connect with Main module PortA


4.7 One Way Incoming Line System Connection Wiring



Different Outgoing Line Circuits Configuration table:

Outgoing Line Circuits	Main Module 1	Main Module 2	Main Module 3	Main Module 4	Note
21 or 42	■	□	□	□	■ Configuration needed □ Configuration no need
63 or 84	■	■	□	□	
105 or 126	■	■	■	□	
147 or 168	■	■	■	■	


4.8 Two Way Incoming Line System Connection Wiring



Different Outgoing Line Circuits Configuration table:

Outgoing Line Circuits	Main Module 1	Main Module 2	Main Module 3	Main Module 4	Note
21 or 42	■	□	■	□	■ Configuration needed
63 or 84	■	■	■	■	□ Configuration no need





4.9 One Main & One Backup Incoming Line System Connection Wiring



Different Outgoing Line Circuits Configuration table:

Outgoing Line Circuits	Main Module 1	Main Module 2	Main Module 3	Main Module 4	Note
21 or 42	■	□	□	□	■ Configuration needed □ Configuration no need
63 or 84	■	■	□	□	
105 or 126	■	■	■	□	
147 or 168	■	■	■	■	

4.10 Multi Main Module Address Setting

Module	Main Module Dial Switch Setting
PMAC202 1	ON  1 2 3 4
PMAC202 2	ON  1 2 3 4
PMAC202 3	ON  1 2 3 4
PMAC202 4	ON  1 2 3 4

5. Display and Operation

5.1 System Configuration


After Power On, power meter display real time data, under real time data interface, press “System Config” button to enter into system configuration interface

Notice

After Power ON, should finish Incoming line mode selection and Outgoing line circuits selection setting first, then to setting other parameters

5.1.1 One way Incoming Line Configuration


Configuration as One way incoming line mode, as picture 5.1



Picture 5.1

5.1.2 Two way Incoming Line Configuration


Configuration as Two way incoming line mode, as picture 5.2



Picture 5.2

5.1.3 One Main & One Backup Incoming Line Configuration


Configuration as Main & Backup incoming line mode, as picture 5.3



Picture 5.3


5.1.4 Clear Energy

Clear Main Module Energy, as picture 5.4




Picture 5.4

5.1.5 Clear Maxim Value




Clear max.data Clear all the Maxim value information in Main Module, e.g. Maxim Current value, Maxim Current Demand etc

5.1.6 Time Synchronization



Time sync. Synchronization time on HMI and Main Module

5.1.7 Function Configuration



Exchange to Information setting interface, as picture 5.5

5.1.8 Setting



Press SET, after input correct password for further operation

5.1.9 Password Input

The screen has a blue header with the text "Confirm password". Below the header, the text "Pls enter password" is displayed in red. There is a "Password" label followed by a text input field and a "Reset" button to its right. At the bottom, there are two buttons: "Confirm" and "Cancel".

when setting Incoming line Clear Maxim value, Time Synchronization, Function

Configuration, Set system configuration, password input table will be shown, further operation can be processed after input correct password. Default password: 201

5.1.10 Password Modification

The screen has a blue header with the text "Reset password". Below the header, the text "Pls enter the old and new password" is displayed in red. There are two text input fields: "Old password" and "New password". At the bottom, there are two buttons: "Confirm" and "Cancel".

Device Information setting interface:

The interface is titled "Main line A Device config (Module- 1)". It is divided into two main sections: "Read Area" and "Write Area".

Read Area:

Model No.	S/N:	Software ver:	Hardware ver:
0	0	0	0

Vgn:	T:	I△n:	DI module num

Write Area:

Set time zone
GMT ▼


At the bottom of the interface, there are three buttons: "Set", "Read", and "Back".

Picture 5.5

5.2 Data Display


5.2.1 Real Time Data Display


Power on the display module you can enter into main interfaced display as below picture 5.6, Display real-time data of one or two incoming line circuit and 21 branch outgoing circuit as well as the status of switch.




Picture 5.6

5.2.2 Switch status display


Incoming Switch:  Is the condition of Incoming Line switch 1 status, green means "OFF", red means "ON". flash means Out-of-Order

Outgoing Switch:  Is the condition of Switch, green means "OFF", red means "ON". flash means Out-of-Order

5.2.3 Alarm display

Alarm  The alarm light will turn red and flash when event happen. Gray means no alarm.

5.2.4 Communication Status Indicate

COM  Green means the communication between display module and main module is normal. Gray means no communication.

5.2.5 Key Operation

Next: Exchange to next System Interface

Incoming Data: Exchange to Incoming data display interface

Outgoing Data: Exchange to Outgoing data display interface

Alarm Record: Exchange to Real-time alarm record interface

System Configuration: Exchange to system configuration interface

5.3 Incoming Circuit Data Display

Display 1 loop incoming circuit real time data, as picture 5.7

IN A Real-time data Dis						
Branch	Phase A	Phase B	Phase C	Total	Neutral line	Unit
V	0	0	0		0	V
I	0	0	0		0	A
Max. I	0	0	0		0	A
Dmd_I	0	0	0			A
Max. dmd_I	0	0	0			A
P	0	0	0	0		W
Dmd_P	0	0	0	0		W
Max. dmd_P	0	0	0	0		W
Q	0	0	0	0		var
THDu	0	0	0			%
THDi	0	0	0			%
Iun				0		%
Total kWh				0.0		kWh
Total kvarh				0		kvarh
PF	0	0	0			
F				0		Hz

historical record
IN set
Back

Picture 5.7

5.4 Outgoing Circuit Data Display

Display multi loop outgoing circuit real time data, as picture 5.8

Branch 1 to 6 real-time data Dis							Module 1 Relay-1: OFF Relay-2: OFF	
Branch line	1	2	3	4	5	6	Unit	
I	0	0	0	0	0	0	A	
Max.I	0	0	0	0	0	0	A	
Dmd_I	0	0	0	0	0	0	A	
Max. dmd_I	0	0	0	0	0	0	A	
P	0	0	0	0	0	0	W	
Dmd_P	0	0	0	0	0	0	W	
Max. dmd_P	0	0	0	0	0	0	W	
Pf	0	0	0	0	0	0		
Q	0	0	0	0	0	0	var	
THDi	0	0	0	0	0	0	%	
kWh	0	0	0	0	0	0	kWh	
kvarh	0	0	0	0	0	0	kvarh	

CT set
Energy record
Set branch
Page up
Page down
Back

Picture 5.8

5.5 Real-time Alarm Record Display

Display Maxim 16 pieces alarm information, as picture 5.9




The screenshot shows a terminal window titled "Real-time alarm". It contains a table with three columns: "Date", "Time", and "Description". The table is currently empty. Below the table, there are four buttons: "Historical alarm", "Page up", "Page down", and "Back".

Date	Time	Description

Picture 5.9

History Information Record:



The screenshot shows a terminal window titled "Historical fault record". It contains a table with three columns: "Date", "Time", and "Description". The table is currently empty. Below the table, there are three buttons: "Page up", "Page down", and "Back".

Date	Time	Description

Picture 5.10

5.6 Incoming Circuit Value Programming

Configure Incoming line circuit parameters and alarm value, as picture 5.11

IN A Set (Module- 1)

COM add:	Baudrate	DI alarm enable	Pulse output opt
0	1200	Disable	Main line

Relay-1 function	Relay-2 function	DI-1 function	DI-2 function	DI-3 function	DI-4 function
Universa	Universa	Universal	Universal	Universal	Universal

CT ratio	1	Current lo-lo-limit:(A)	0	Neutral current hi-limit:	0
Temperature hi-limit:	0	Current lo-limit:(A)	0	Current unbalance limit:	0
Voltage lo-limit:(V)	0	Current hi-limit:(A)	0	Leakage current hi-limit:	0
Voltage hi-limit:(V)	0	Current hi-hi-limit:(A)	0	Vgn hi-limit:	0


Picture 5.11

Items	Range of data	Definition
Communication Add	1~247	Initial value is 1
CT Ratio	1~100	Initial value is 1
Baud Rate	1200、2400、4800、9600、19200 or 38400	Initial value is 19200
DI Alarm Enabled	Enable, Disable	Enable: Permit DI alarm Disable: Forbid DI alarm
Pulse Output Option	Main line, Branch 1-42	Incoming Circuit: Energy pulse output option is incoming Outgoing Circuit: Energy pulse output option to each relative outgoing circuit
Relay function	Universal Relay RUN Indication Alarm In Alarm Out Alarm	Universal relay: can be controlled by Modbus function code 05. Equipment working instruction: act after equipment work. Alarm output: act after main or branch circuit alarm. Incoming line branch circuit alarm: act after main circuit alarm. Outgoing line branch circuit alarm: act after branch circuit alarm. Relay initial setting: Relay 1 & 2 are all alarm output

Switch Status function	Universal switch, Incoming line switch, Surge protection switch	Surge protection switch: Incoming line switch status can be setting as lighting protection switch, after setting, the main interface will has a lighting protection switch display. If the switch OFF then means the lighting protection switch OFF
Current low-low level alarm value	5~650A, 0 means alarm closed	Alarm action: over 0 and less than setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current low level alarm value	5~650A, 0 means alarm closed.	Alarm action: over low-low level alarm value and smaller than setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current high level alarm value	5.0~650A, 0 means alarm closed.	Alarm action: over the setting value and smaller than low-low level alarm value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current high-high level alarm value	5.0~650A, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Neutral current high level alarm value	5.0~650A, 0 means alarm closed.	Alarm action: the current value is over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current unbalance rate alarm value	5.0~100%, 0 means alarm closed.	Alarm action: over than the setting value. Alarm reset: delay 5s after the alarm condition is eliminated. Unbalance calculation formula: $(I_{max}-I_{min})/I_{max} \times 100\%$ I _{max} : 3 phase current maxim value I _{min} : 3 phase current minimum value
Voltage low level alarm value	20~300V, 0 means alarm closed.	Alarm action: over 0 and smaller than setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Voltage high level alarm value	20~300V, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Temperature high level alarm value	30--120, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Leakage current high level alarm value	0.1—1A, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Null-Earth voltage high level alarm value	2—10V, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.

5.7 Outgoing Circuit Value Programming

Outgoing circuit alarm setting as picture 5.12



Picture 5.12

Items	Parameter	Definition
Current low-low level alarm value	5.0~250.0A, 0 means alarm closed.	Alarm action: over 0 and smaller than setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current low level alarm value	5.0~250.0A, 0 means alarm closed.	Alarm action: over the low-low level alarm value and smaller than setting value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current high level alarm value	5.0~250.0A, 0 means alarm closed.	Alarm action: over the setting value and smaller than high-high level alarm value. Alarm reset: delay 5s after the alarm condition is eliminated.
Current high-high level alarm value	5.0~250.0A, 0 means alarm closed.	Alarm action: over the setting value. Alarm reset: delay 5s after the alarm condition is eliminated.

5.8 History Electrical Degree

Display historical Year electrical degree value, as picture 5.13

XXXX	Year	Branch	1	to	42	Yearly Kwh	IN	0.0	kWh
Branch line	1	2	3	4	5	6	7	Unit	
Energy data	0	0	0	0	0	0	0	kWh	
Branch line	8	9	10	11	12	13	14	Unit	
Energy data	0	0	0	0	0	0	0	kWh	
Branch line	15	16	17	18	19	20	21	Unit	
Energy data	0	0	0	0	0	0	0	kWh	
Branch line	22	23	24	25	26	27	28	Unit	
Energy data	0	0	0	0	0	0	0	kWh	
Branch line	29	30	31	32	33	34	35	Unit	
Energy data	0	0	0	0	0	0	0	kWh	
Branch line	36	37	38	39	40	41	42	Unit	
Energy data	0	0	0	0	0	0	0	kWh	

Search data of last Year

Picture 5.13

Display historical Month electrical degree value, as picture 5.14

XXXX	Year	XX	Mon	1	to	42	Monthly Kwh	IN	0.0	kWh
Branch line	1	2	3	4	5	6	7	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch line	8	9	10	11	12	13	14	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch line	15	16	17	18	19	20	21	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch line	22	23	24	25	26	27	28	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch line	29	30	31	32	33	34	35	Unit		
Energy data	0	0	0	0	0	0	0	kWh		
Branch line	36	37	38	39	40	41	42	Unit		
Energy data	0	0	0	0	0	0	0	kWh		

Search data of last Mon

Picture 5.14

5.9 CT Setting

Notice

CT specification will be effective after be revised need power ON again, revise phase position configuration no need re-power on, please make sure connection sequence and configuration correspondence

Display CT specification as picture 5.15

Branch 1 to 21 CT config			
1 - 3	4 - 6	7 - 9	10 - 12
<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A
<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A
<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A
13 - 15	16 - 18	19 - 21	
<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	<input checked="" type="radio"/> 50A	
<input type="radio"/> 100A	<input type="radio"/> 100A	<input type="radio"/> 100A	
<input type="radio"/> 200A	<input type="radio"/> 200A	<input type="radio"/> 200A	

Buttons: Set phase position, Set, Read, Back

Picture 5.15

Phase position configuration interface

Branch 1 to 21 phase position config			
A B C	A B C	A B C	A B C
1 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	4 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	7 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	10 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>
2 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	5 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	8 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	11 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>
3 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	6 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	9 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	12 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>
A B C	A B C	A B C	
13 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	16 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	19 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	
14 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	17 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	20 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	
15 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	18 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	21 <input checked="" type="radio"/> <input type="radio"/> <input type="radio"/>	

Buttons: CT config, Set, Read, Back

Picture 5.16

6. Maintenance and Trouble Shooting

Possible Question	Possible Reason	Solutions
Device no display after add control source	The power did not add to the device	Check the power supply terminals on device to make sure whether add correct operating voltage Check the source control fuse not be burned
Measuring value not correct or non-conformance with expect value	Voltage measurement not correct	Check measuring voltage whether match with rated parameter Check connection wiring
	Current measurement not correct	Check measuring current whether match with rated parameter Check CT parameter Check connection wiring
	Power measurement not correct	Check voltage / current phase sequence Check current dotted terminal Check CT phase sequence
Outgoing Circuit Switch Status no operation	Status module communication stop	Check status module communication indicate light Check status module communication connection wiring
	Switch status operation voltage incorrect	Check outside node types whether match with device rated parameter Check outside connection wiring
Main module can not connect with Host computer	Communication address incorrect	Check device communication address
	Communication baud rate incorrect	Check device communication baud rate
	Communication interference	Check communication shield layer
	Communication stop	Check communication cable
	System configuration not match with main module	Check system configuration Check main module dial switch